

## Importing / Exporting Configurations


### Mindray ePM Patient Monitor


#### How to download ePM Standard configurations from the Mindray UK Website:



- Visit [www.mindrayuk.com/education](http://www.mindrayuk.com/education)
- Find the ePM Standard Configuration zip file and download onto PC. Please note an encrypted USB stick cannot be used
- Unzip the file and copy the **mrbigdipercfg** folder and the **mrbigdiperUser** folder to a USB stick

#### To import the configuration from the USB drive to the monitor, follow this procedure:

- Connect the USB drive to the monitor's USB port
- Select the **Main Menu** quick key → swipe to the **Configuration** column → select **Manage**




- Input the password **315666** and select 
- Ensure the **Default Patient Category** is selected and whether **Default Use EWS** is **Yes** or **No**
- Select **Import Configuration** → select the **Configurations** and **User Maintenance Settings** to import → select **Import** → select **Back**
- 



These guidelines do **NOT** replace the instructions for use and all users should refer to the appropriate **Operator's Manual** for detailed instructions. The Illustrations may not necessarily reflect the setup or data displayed on your device.

## To set the default configuration, follow this procedure:


- In the **Manage Configuration** menu choose **Select Default Config** → select **Load Specified Config**




- Press the area labelled **Defaults** located next to **Default Adult Config** / **Default Ped Config** / **Default Neo Config** → select appropriate configuration → select **Back** → select **X** to exit the menus

## To export the configuration to the USB drive from the monitor, follow this procedure:

- Connect the USB drive to the monitor's USB port
- Select the **Main Menu** quick key → swipe to the **Configuration** column → select **Manage**



- Input the password **315666** and select
- Select **Export Configuration** → select the **Configurations** and **User Maintenance Settings** to Export → select **Export** → select **Back**



These guidelines do **NOT** replace the instructions for use and all users should refer to the appropriate **Operator's Manual** for detailed instructions.  
The illustrations may not necessarily reflect the setup or data displayed on your device.